


NIT HAMIRPUR



MAJOR PROJECT



OUR TEAM

MENTOR

Dr. Jeetendrarsingh
Maan

Shivam
Birla

20BMA029

Siddharth
Dani

20BMA004

Kunal
Singh

20BMA022

APPLICATIONS OF WAVELET TRANSFORM

01

IMAGE FUSION

02

IMAGE COMPRESSION

03

IMAGE DENOISING

04

EEG AND ECG SIGNALS

- Breaking down input data into approximation and detail coefficients
- We perform different operations on these coefficients and reconstruct the output data by using operated coefficients .
- Approximation coefficients act as low -pass filter
- Detail coefficients act as high-pass filter

COEFFICIENTS

- All the coefficients are of size $M/2 \times M/2$, if the size of original image was $M \times M$
- Approximation coefficients act as smoothing filter
- Detail coefficients act as line and edge detectors
- 3 types of detail coefficients exist : Horizontal , Vertical and Diagonal . All act as high pass filters as per their names

Common naming style for coefficients

cA - Approximation coefficients

cV - Vertical coefficients

cH - Horizontal coefficients

cD - Diagonal Coefficients

LEVEL 1 DECOMPOSITION

M

Image

M



$M/2$

$M/2$

$M/2$

cA

cH

$M/2$

$M/2$

cV

cD


$M/2$

$M/2$


$M/2$

RESULTS


Haar wavlet
(level 600)




Coiflet wavlet
(level 6)



Symlet wavelet
(level 4)



Daubecius
(level 5)



Haar Transform

Suppose we want to apply haar transform on vector

$$\begin{bmatrix} 1 \\ 2 \\ 3 \\ 4 \end{bmatrix}$$



Haar Matrix

$$\frac{1}{\sqrt{2}} \begin{bmatrix} 1 & 1 & 1 & 1 \\ 1 & 1 & -1 & -1 \\ \sqrt{2} & -\sqrt{2} & 0 & 0 \\ 0 & 0 & \sqrt{2} & -\sqrt{2} \end{bmatrix}$$

Inverse Haar Matrix


$$\frac{1}{\sqrt{2}} \begin{bmatrix} 1 & 1 & \sqrt{2} & 0 \\ 1 & 1 & -\sqrt{2} & 0 \\ 1 & -1 & 0 & \sqrt{2} \\ 1 & -1 & 0 & -\sqrt{2} \end{bmatrix}$$

IMAGE FUSION



Procedure

Decomposition → Apply the min-max-mean
method of fusion by
Petrovic and Xydeas (2004) → Reconstruction



Fusion Rules

Image 1

cA1	cH1
cV1	cD1

Image2

cA2	cH2
cV2	cD2




Operation1
(cA1 , cA2)

Operation2
(cH1 , cH2)


Operation2
(cV1 , cV2)

Operation2
(cD1 , cD2)



RESULTS



MaxMax image



MinMax image



MinMin image

Image Compression

Lossless wavelet compression

- Data is lost but information is saved
- dwt and idwt functions applies thresholding due to upsampling and downsampling
- Thats why our image will be compressed if we deconstruct and reconstruct our image using these functions .
- For example : Approximation coefficients is created by downsampling (by 2) the original , once row wise and once column wise

Downsampling by 2

[1, 2, 3, 4, 5, 6, 7, 8]

[1, 3, 5, 7]

Upsampling by 2


[1, 3, 5, 7]

[1, 0, 3, 0, 5, 0, 7]

Result

Compression ratio : 1.65

original




lena256rgb

PNG File

152 KB

compressed



level3Compression


PNG File

91.9 KB

We apply quantization on all the coefficients

Quantization :

```
new = round( old / quantization_step) * quantization_step
```



Quantization step

1

Compression ratio



1.57

10

3.35

100

16.15



Quantization is applied on fast fourier transform

	Wavelet	Fast fourier
Compression ratio	8.88	8.88
Size	17.2 KB	17.2 KB






Image denoising

- Hard and Soft thresholding is applied to the coefficients



Results

- Size also decreases on thresholding

Soft Thresholding



Noisy Image (Added Gaussian Noise)



Hard Thresholding



EEG and ECG signal

- EEG - brain signal
- ECG - heart signal
- Continuous wavelet transform will be used

THANK YOU